Edison V3 sticker placement guide

Place stickers on the front and rear orange surfaces as indicated by the green dotted lines.

Before applying: make sure the surface is clean and dry. Position the sticker carefully, then press firmly.

Keep these areas uncovered (marked in red):

- **Clear front section:** covering it interferes with obstacle detection.
- **Two rear EdCharger contact holes:** covering them prevents charging through these contacts.
- **Four speaker holes:** covering them reduces speaker volume and clap-detection sensitivity.

Face stickers - front



Place face stickers on the front orange surface. Do not cover the clear front section.

Name and number stickers - rear



Place name and large number stickers on the rear orange surface. Do not cover the EdCharger contact holes.

Use small matching numbers on EdRemote or EdCharger



Use the same number on Edison V3 and its EdRemote so students can identify the matching pair.



Match each charging bay's number to an Edison V3 so students know where to return it.