## Activity

Before we start programming Edison, let's get to know Edison. In the pictures below you can see all of Edison's different parts. Can you find all of these parts on your Edison robot?

Top of Edison:

Speaker and sound sensor

Keypad

Play button, press to turn on or start a program

Stop button, press to stop a program or hold to turn off

Record button

Bottom of Edison:

USB cable for programming and recharging

Line tracking sensor

Front of Edison:

Right light sensor

Right infrared LED

Right red LED

Left light sensor

Left infrared LED

Left red LED